# **Ampacity**

The current a conductor can carry continuously without exceeding its temperature rating. Ampacity is a function of cable size, insulation type and the conditions of use.

# **Ampere Rating**

The continuous current carrying capability of a fuse under defined laboratory conditions. The ampere rating is marked on each fuse. Class L fuses and E rated fuses may be loaded to 100% of their ampere rating. For all other fuses, continuous load current should not exceed 80% of fuse ampere rating.

### **Available Fault Current**

The maximum short circuit current that can flow in an unprotected circuit.

#### **Bolt-in Fuse**

A fuse which is intended to be bolted directly to bus bars, contact pads or fuse blocks.

### **Contacts**

The external live parts of the fuse which provide continuity between the fuse and the balance of the circuit. Also referred to as ferrules, blades or terminals.

### Coordination

The use of overcurrent protective devices which will isolate only that portion of an electrical system which has been overloaded or faulted. See Selectivity.

# **Current-Limiting Fuse**

A fuse which will limit both the magnitude and duration of current flow under short circuit conditions.

# **Current-Limiting Range**

The available fault current a fuse will clear in less than 1/2 cycle, thus limiting the actual magnitude of current flow.

### **Dual Element Fuse**

Often confused with time delay, dual element is a term describing fuse element construction. A fuse having two current responsive elements in series.

#### **Element**

A calibrated conductor inside a fuse which melts when subjected to excessive current. The element is enclosed by the fuse body and may be surrounded by an arc-quenching medium such as silica sand. The element is sometimes referred to as a link.

#### **Fault**

An accidental condition in which a current path becomes available which by-passes the connected load.

#### **Fault Current**

The amount of current flowing in a faulted circuit.

# **Fuse**

An overcurrent protective device containing a calibrated current carrying member which melts and opens a circuit under specified overcurrent conditions.

# I2t (Ampere Squared Seconds)

A measure of the thermal energy associated with current flow.  $I^2t$  is equal to  $(I_{RMS})^2 \times t$ , where t is the duration of current flow in seconds.

**Clearing I**<sup>2</sup>**t** is the total I<sup>2</sup>t passed by a fuse as the fuse clears a fault, with t being equal to the time elapsed from the initiation of the fault to the instant the fault has been cleared.

**Melting I**<sup>2</sup>**t** is the minimum I<sup>2</sup>t required to melt the fuse element.

# Interrupting Rating (Abbreviated I.R.)

The maximum current a fuse can safely interrupt. Some special purpose fuses may also have a "Minimum Interrupting Rating". This defines the minimum current that a fuse can safely interrupt.

### Kiloamperes (abbreviated kA)

1,000 amperes.

# **Limiter or Back-up Fuse**

A special purpose fuse which is intended to provide short circuit protection only.

# **Overcurrent**

Any current in excess of conductor ampacity or equipment continuous current rating.



#### **Overload**

The operation of conductors or equipment at a current level that will cause damage if allowed to persist.

# Peak Let-Thru Current (In)

The maximum instantaneous current passed by a current-limiting fuse when clearing a fault current of specified magnitude.

# **Rejection Fuse Block**

A fuse block which will only accept fuses of a specific UL class. Rejection is a safety feature intended to prevent the insertion of a fuse with an inadequate voltage or interrupting rating.

### **Rejection Fuse**

A current-limiting fuse with high interrupting rating and with unique dimensions or mounting provisions.

### **Renewable Fuse**

A fuse which can be restored for service by the replacement of its element.

### **Renewable Element or Link**

The field-replaceable element of a renewable fuse. Also referred to as a renewable link.

# **Selectivity**

A main fuse and a branch fuse are said to be selective if the branch fuse will clear all overcurrent conditions before the main fuse opens. Selectivity is desirable because it limits outage to that portion of the circuit which has been overloaded or faulted. Also called selective coordination.

# **Semiconductor Fuse**

An extremely fast acting fuse intended for the protection of power semiconductors. Sometimes referred to as a rectifier or ultra fast fuse.

# **Short Circuit**

Excessive current flow caused by insulation breakdown or wiring error.

### **Threshold Current**

The minimum available fault current at which a fuse is current limiting.

### **Time-Delay Fuse**

A fuse which will carry an overcurrent of a specified magnitude for a minimum specified time without opening. The specified current and time requirements are defined in the UL/CSA/NOM 248 fuse standards.

### **Voltage Rating**

The maximum voltage at which a fuse is designed to operate. Voltage ratings are assumed to be for AC unless specifically labeled as DC.

### High Voltage (over 34,500V)

Expulsion-Type power fuses are available for nominal voltages of 46, 69, 115, 138 and 161kV in current ratings up to 400 amperes. ANSI (American National Standards Institute) Standards are followed.

### **Medium Voltage (601-34,500V)**

**Current-Limiting or Expulsion-Type Power Fuses** are general purpose fuses available for nominal voltages of 2.4, 2.75, 4.16, 5.5, 7.2, 8.25, 14.4, 15.5, 23 and 34.5kV in current ratings up to 720 amperes. ANSI and UL Standards are followed.

Current-Limiting Motor Starter Fuses are available for nominal voltages of 2.4, 4.8 and 7.2kV in current ratings up to 36R (650A). These are special purpose R-Rated fuses for motor short circuit protection only (back-up fuses) and are not full-range power fuses. ANSI and UL Standards are followed.

**PT Fuses (Potential Transformers)** require current limiting fuses or equivalent on the primary connection side. Standard PT primary voltages range from 2.4kV to 36kV. Since the power requirement is low (for relays, metering, etc.) fuses of the proper voltage are applied in the 1/2 to 5 ampere range. Several voltage ratings are available, physical sizes vary among manufacturers.

# Low Voltage (600V or less)

Many types of low voltage fuses are classified and identified for use in 125, 250, 300, 480, or 600V circuits. UL/CSA/NOM standards are followed. Common types are briefly summarized in the chart on the next page.

